



RT 10 WEST PO BOX 638 CLINTON IL. PHONE 217-935-2384
FAX 217-935-4611

AFM-0105 86-93 N.A. Power Pipe® for Pro-M 77-83 mm
shorty meters

This product is for off road use only
INSTRUCTION

Thank you for purchasing an **AFM** product. If you have any question please call 217-935-2384

1. Remove the air cleaner, mass air and inlet rubber hose to throttle body.
2. Locate the existing 3 1/2" round hole on the passenger side apron. This is where your AFM Power Pipe® is going to enter the fenderwell.
3. Remove the rubber elbow from the straight end of the Power Pipe® and slide the straight end through the hole.
4. Slide the other end (with rubber sleeve) on to your throttle body and tighten clamps.
5. Lube up the inside of the rubber elbow with WD-40 so it will slide on the Power Pipe® easier.
6. Slide the elbow on the straight end of the Power Pipe® sticking through the inner fenderwell. This works best by turning the elbow back and forth.
7. Now slide your mass air into the rubber elbow and let it rest on the plastic inner fenderwell and tighten all clamps.
8. Plug in your mass air wiring harness. The wiring should be long enough. Most are, but if not, cut wire and add the additional length you need.

To increase the air flow through your new AFM Power Pipe®, we strongly suggest the use of one of our AFM Power Stack air cleaner which flows 10-20% more than conventional conical air cleaners. For pricing and availability, please call our order line at 1-800-234-3106.