



RT 10 WEST PO BOX 638 CLINTON IL. PHONE 217-935-2384

FAX 217-935-4611

AFM-0107c/ck/ck90/c92 99-02 Lightning Power Pipe®

INSTRUCTION

This product is for off road use only

Thank you for purchasing an **AFM** product. If you have any question please call 217-935-2384

1. Unplug the three hoses to factory rubber inlet hose one 1/4 one 5/8 and one 3/4
2. Unplug the mass air and ACT sensor.
3. Remove ACT sensor out of air box and save for later.
4. Remove the factory air box, air cleaner, mass air and rubber inlet hose to throttle body
(If you have purchased the AF-0107c Power Pipe or AF-0107c92 Power Pipe® kit skip down to no. 8)
5. Remove Mass Air from air box and rubber inlet hose
6. Bolt air filter flange to 90mm stock mass air, using 1/4 bolts. Slide air filter supplied onto mass air.
8. Slide mass air onto Power Pipe.
10. Slide Power Pipe assemble on to throttle body and lay mass air and air filter back where stock air box was sitting
11. Install extra hose provided onto the 5/8 PCV line and Plug into Power Pipe.
12. Run I.A.C hose under radiator hose and install extra 3/4 hose provided to connect to Power Pipe
13. Plug in last 1/4 hose fitting into Power Pipe
14. Install ACT sensor into hole provided on elbow on Power Pipe and plug in wire harness.
15. Check all clamps and plug in mass air harness.