



**RT 10 WEST PO BOX 638 CLINTON IL. PHONE 217-935-2384
FAX 217-935-4611**

***AFM*-0119 94-95 Mustang N.A. Power Pipe® for Pro-M
77-83 shorty meters**

This product is for off road use only

INSTRUCTION

Thank you for purchasing an ***AFM*** product. If you have any question please call 217-935-2384

1. Remove the air cleaner, mass air and inlet rubber hose to throttle body.
2. Locate the ACT sensor and the hose from valve cover stand and remove for later use.
3. Take the rubber elbow provided and slide it onto the straight end of the pipe.
4. Locate the hump hose and put the act sensor into the 7/16 hole on the side of it and place onto the curved end of the steel Power Pipe® with the act sensor position to face the engine compartment.
5. Slide it into the fender well through the front opening and slide it up and onto the throttle body and loosely put the clamp on.
6. Slide the mass air under the car and up into the hump hose and tighten hose clamp.
7. Move around the position of the rubber elbow and Power Pipe_R so it misses the alternator and clamp down.
8. Plug in the mass air and act sensor if wiring is not long enough unwrap from wire loom.
9. Take the hose that comes from the valve cover stand and run to the inner fender well or put a breather on the valve cover stand.
10. Tighten all clamps.