



RT 10 WEST PO BOX 638 CLINTON IL. PHONE 217-935-2384
FAX 217-935-4611

AFM-0129 86-93 Mustang with Drivers side S/C for Pro-
M 77-83 shorty meters

This product is for off road use only

INSTRUCTION

Thank you for purchasing an **AFM** product. If you have any question please call 217-935-2384

1. Take the mondo by-pass and install it on the discharge tube with the opening facing toward the firewall.
2. Install discharge pipe on the S/C and throttle body.
3. Take one of the hoses provided .The hose that has 8# on one end and 17# on the other. Slide the 17# end behind the intake and fit the 8# onto to the by-pass.
4. Install the 2# metal pipe provided into the 17# end and slide on the remaining hose.
5. Slide on clamps and leave loose.
6. Install Power Pipe and fit 2# hose up to it.
- 7 Slide on hump hose and install Mass air..
8. Tighten all clamps.
9. You will need to lengthen wires for mass air, make sure you solder them.

To increase the air flow through your new AFM Power Pipe®, we strongly suggest the use of one of our AFM Power Stack air cleaner which flows 10-20% more than conventional conical air cleaners. For pricing and availability, please call our order line at 1-800-234-3106.