



PO BOX 638 RT 10 WEST CLINTON, IL 61753
Phone 217-935-3106 Fax 217-935-4611 Rick 217-935-2384
www.andersonfordmotorsport.com

Tappet Tool

AF-0601

instruction

Thank you for purchasing an **AFM** products. The Tappet Tool is very easy to use and will work with most hydraulic or solid roller tappet V8 application. We are going to explain how to use it on 5.0 HO fuel injected Mustangs.

1. Remove off the upper intake, valve covers, rocker arms and push rods.
2. Take the magnet rods and screw the wing nuts to the top to start with.
3. Slide them in the push rod holes till you feel them catch the tappet.
4. Hold the wing nut and turn the rod slowly while moving it up and down till there is no movement. (If you go to far you will loose the tappet and have to start over.)
5. When you have done this to all 16 magnet rods. **Double check yourself and make sure you have them all pulled up and have not lost a Tappet.**
6. You are ready to change cams.
7. After you have changed cams just pull up on the magnet rods to break loose the tappets
8. Your ready to reassemble.

If you have any questions call 1-217-935-2384.