



PO BOX 638 RT 10 WEST CLINTON, IL 61753
Phone 217-935-2076 Fax 217-935-4611 Rick 217-935-2384
www.andersonfordmotorsport.com
AF-0120c

(Only for use with Professional mass air systems 80mm Pro-m mass-air)

1. Disconnect the negative battery cable.
2. Unplug the mass air and remove the Vortech intake pipe and air filter to Super Charger and unplug breather hoses to valve cover.
3. Remove two screws holding purge flow valve to shock tower and move out of way.
4. Remove black push in retainer from frame rail by shock tower
5. Slide heat shield in place. Start front first by sliding under radiator cover and then lower back down into place.
6. Use black push in retainer and install through bracket on heat shield and back into original hole.
7. Put purge flow valve back into place and reinstall screws.
8. Plug in wire harness(provided) and run mass air wiring through slice in heat shield.
9. Install rubber elbow onto intake side of super charger.
10. Slide Power Pipe® onto rubber elbow and over heat shield.
11. Put hump hose on the end of Power Pipe® and install act sensor in hole provided.
12. Slide Pro-M 80mm Mass Air onto Power Pipe®. Sensor facing forward. Angle meter if needed to provide clearance for air cleaner.
11. Plug in wiring Mass Air and ACT sensor.
12. Install breather (provided) on to passenger side valve cover, where breather connection was.
13. Hook up battery and cycle key three times and you ready to go.

If you have any questions call 1-217-935-2384.