



PO BOX 638 RT 10 WEST CLINTON, IL 61753
Phone 217-935-2076 Fax 217-935-4611 Rick 217-935-2384
www.andersonfordmotorsport.com

AF-0121c

This Power Pipe® is designed to increase the efficiency of your Procharger. With the limited space provided on the GT. **The Power Pipe® will FOR SURE touch your hood insulator and hood.** If you do not want this please call for a return number for the Power Pipe.

1. Remove Pro Charger original intake pipe and air filter.
2. Take bolt out (Procharger supplied bolt) in vapor control bracket and move bracket back one hole.
3. Slide rubber elbow on to the super charger. Snug up hose clamp.
4. Slide Power Pipe® into rubber elbow and turn both toward engine.
5. Slide air filter on to Power Pipe® And move as close as you can to engine and tighten all clamps.

If you have any questions call 1-217-935-2384.