



PO BOX 638 RT 10 WEST CLINTON, IL 61753
Phone 217-935-2076 Fax 217-935-4611 Rick 217-935-2384
www.andersonfordmotorsport.com
AF-0123c
(Only for use with Velocity mass air)

1. Disconnect negative battery cable.
2. Unplug mass air and remove air box with elbow to throttle body and breather connection to valve cover.
3. Remove two screws holding purge flow valve to shock tower and move out of way.
4. Remove black push in retainer from frame rail by shock tower
5. Slide heat shield in place. Start front first by sliding under radiator cover and then lower back down into place.
6. Use black push in retainer and install through bracket on heat shield and back into original hole.
7. Put purge flow valve back into place and reinstall screws.
8. Plug in wire harness(provided) and run mass air wiring through bottom of hole in heat shield.
9. Slide Power Pipe® through hole in heat shield and slide onto throttle body.
10. Slide Velocity Mass Air onto Power Pipe®. Sensor facing forward. Angle meter if needed to provide clearance for air cleaner.
11. Plug in wiring Mass Air .
12. Install breather (provided) on to passenger side valve cover, where breather connection was.
13. Hook up battery and cycle key three times and you ready to go.

If you have any questions call 1-217-935-2384.