



RT 10 WEST PO BOX 638 CLINTON IL. PHONE 217-935-2384
FAX 217-935-4611

AFM-0104 86-93 N.A. Power Pipe® for C&L and Bullet mass airs

This product is for off road use only
INSTRUCTION

Thank you for purchasing an **AFM** product. If you have any question please call 217-935-2384

1. Remove the air cleaner, mass air and inlet rubber hose to throttle body.
2. Locate the existing 3 1/2" round hole on the passenger side apron. This is where your AFM Power Pipe® is going to enter the fenderwell.
3. Place the Power Pipe® in this opening with the long end first.
4. install your mass air into the rubber elbow provided and mount the rubber elbow onto the throttle body.
5. Fit the rubber sleeve provided onto the Power Pipe® and slide onto the mass air.
6. Slide your air cleaner into the inner fenderwell and onto the steel elbow and let it rest on the plastic inner fenderwell
7. Tighten all clamps and plug in mass air.