



**RT 10 WEST PO BOX 638 CLINTON IL. PHONE 217-935-2384
FAX 217-935-4611**

***AFM*-0116 99-01 Cobra N.A. Power Pipe® for Pro-M
77-83 shorty meters**

This product is for off road use only

INSTRUCTION

Thank you for purchasing an ***AFM*** product. If you have any question please call 217-935-2384

1. Remove the air cleaner, mass air and inlet rubber hose to throttle body.
2. Locate the ACT sensor and the hose from valve cover for later use.
3. Take the rubber elbow provided and put it on the throttle body. It will seem to big, but it will clamp down. (This is done on purpose to give it a venturi effect, which helps on throttle response)
4. Locate the hump hose and put the act sensor into the 7/16 hole on the side of it and place onto the curved end of the steel Power Pipe® with the act sensor position to face the engine compartment.
5. Slide it into the fenderwell through the front opening and slide it up to and into the rubber elbow and loosely put the clamp on.
6. Slide the mass air under the car and up into the hump hose and tighten hose clamp.
7. Move around the position of the rubber elbow and Power Pipe® so it misses the valve cover a 1/2 inch and clamp down.
8. Plug in the mass air and act sensor if wiring is not long enough unwrap from wire loom.
9. Install the hose (provided) that will go from the valve cover to the Power Pipe® and tighten all clamps.

To increase the air flow through your new AFM Power Pipe®, we strongly suggest the use of one of our AFM Power Stack air cleaner which flows 10-20% more than conventional conical air cleaners. For pricing and availability, please call our order line at 1-800-234-3106.