



RT 10 WEST PO BOX 638 CLINTON IL. PHONE 217-935-2384  
FAX 217-935-4611

**AFM**-0118 Power Pipe® for 96-01 GT with Kenny Bell Super charger using Abaco 85/97 or Pro-M 77-83 shorty meters

This product is for off road use only  
**INSTRUCTION**

Thank you for purchasing an **AFM** product. If you have any question please call 217-935-2384

1. Remove the air cleaner, mass air and inlet rubber hose to throttle body and valve cover.
2. Locate the ACT sensor and the hose from valve cover for later use.
3. Take the rubber elbow with insert provided and put it on the throttle body. It will seem to be big, but it will clamp down. (This is done on purpose to give it a Ventura effect, which helps on throttle response)
4. Locate the hump hose and put the act sensor into the 7/16 hole on the side of it and place onto the curved end of the steel Power Pipe® with the act sensor positioned to face the engine compartment.
5. Slide the Power Pipe® into the fender well through the front opening and slide it up to and into the rubber elbow and loosely put the clamp on.
6. Slide the mass air under the car and up into the hump hose and tighten hose clamp.
7. Plug in the mass air and act sensor. If, wiring is not long enough unwrap from wire loom and re-route.
8. Install the hose (provided) that will go onto the tube coming from the valve cover to the Power Pipe®.
9. Install the hose to Power Pipe® from air by-pass and tighten all clamps.

To increase the air flow through your new AFM Power Pipe®, we strongly suggest the use of one of our AFM Power Stack air cleaner which flows 10-20% more than conventional conical air cleaners. For pricing and availability, please call our order line at 1-800-234-3106