



PO BOX 638 RT 10 WEST CLINTON, IL 61753
Phone 217-935-2076 Fax 217-935-4611 Rick 217-935-2384
www.andersonfordmotorsport.com

Mr. Freeze

Instruction

Thank you for purchasing an **AFM** product

1. Find a good mounting spot for Mr. Freeze we recommend on 79-92 Mustangs on the driver side behind the radiator on the frame. (Mr. Freeze must be mounted lower than S.C. intake pipe) Drill two holes in the frame and mount Mr. Freeze.
2. Locate the 7/32 hose with the jet in the end of the hose.
3. Route it nicely with no kinks in it to the intake pipe of the supercharger.
4. (If you do not have a Power Pipe go to step 6) Make a mark on the rubber elbow on the Power Pipe at a angle that would place the jet at a direction to spray at the super charger impeller.
5. Take an awl and push into the rubber elbow till you have about a 3/16 hole. Step 8 next
6. Make a mark on the inlet pipe or elbow as close as you can to make sure Mr. Freeze sprays towards the supercharger.
7. Drill a 3/8 hole at the mark and install rubber grommet (provided) in place.
8. Push the brass jet threw the hole that you have made and secure extra hose.
9. Route the 1/4 hose from Mr. Freeze to a good vacuum / boost source on intake and secure hose.
10. Pour in a 50/50 mix of Methanol / water or -20 windshield washer fluid and you are ready to start tuning.

If you have any questions call 1-217-935-2384.