



PO BOX 638 RT 10 WEST CLINTON, IL 61753
Phone 217-935-2076 Fax 217-935-4611 Rick 217-935-2384
www.andersonfordmotorsport.com

AF-0120c

(Only for use with Abaco DBX-97b mass-air meter)

1. unplug breather hoses to valve cover and hose to supercharger by-pass from Vortech pipe.
2. Unplug the mass air and remove the Vortech intake pipe and air filter to Super Charger.
2. Remove 6mm bolt from ABS control bracket.
3. Take the AFM aluminum heat shield and slide it front 1st into place and reinstall 6mm bolt.
4. Plug in wire harness(provided) and run mass air wiring through slice in heat shield.
5. Install rubber elbow onto intake side of super charger and hook bypass hose back up.
6. Slide Power Pipe® onto rubber elbow and over heat shield.
7. Put hose on the end of Power Pipe® with stand and position stand to hold meter square.
8. Slide DBX-97b with air filter on to hose. Angle top of meter toward heat shield.
9. Plug in wiring to Mass Air
10. Install breather (provided) on to passenger side valve cover, where breather connection was.
11. Adjust Power Pipe® and mass air for clearance and tighten all clamps
12. Now ready to tune



Any question call 217-935-2384