



PO BOX 638 RT 10 WEST CLINTON, IL 61753  
Phone 217-935-2076 Fax 217-935-4611 Rick 217-935-2384  
[www.andersonfordmotorsport.com](http://www.andersonfordmotorsport.com)

## **LOADTuner**

### **Instruction**

Thank you for purchasing an **Anderson** product

1. Find a good mounting spot for the LOADTuner we recommend on Mustangs under the dash or in the glove box.
2. Find or make a small hole in firewall and run the wire through and up to the mass air.
3. On the mass air sensor it says A B C D. Take the wires coming from the LOADTuner and hook up as follows

Black: Splice into C wire

Red: Splice into A wire

Yellow: Cut D wire. hook up to wire going to MAS air

Orange: Hook up to D wire going back to ECU

You are ready to start tuning.

If you have any questions call 1-217-935-2384.